

Gamma 7.5 & 10kW Operating Manual and User Guide

Version 1.0 May 2010



PTEK LLC
1723 Little Orchard Street—Unit D
San Jose, CA 95125
Phone—(408) 448-3342 / (888) 889-2958
Fax—(408) 448-3342
World Wide Web—<http://www.ptekpower.com>

PTEK LLC reserves the right to revise and change any and all information included in this document.

Copyright © 2009 PTEK LLC

ALL RIGHTS RESERVED. No part of this publication may be reproduced in any form, by photocopy, microfilm, retrieval system, or by any other means now known or hereafter invented without the prior written permission of PTEK LLC.

The information in this publication has been carefully checked and is believed to be accurate. However, PTEK assumes no responsibility for inaccuracies. PTEK LLC retains the right to make changes to this publication at any time without prior notice. PTEK does not assume any liability arising from the application or use of this publication or the product(s) described herein.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the United States Government is subject to the restrictions set forth in DFARS 252.227-7013 (c)(1)(ii) and FAR 52.227-19.

TRADE MARKS and SERVICE MARKS

PTEK[®] is a registered trademark of PTEK LLC (Limited Liability Corporation).

All other trademarks, servicemarks, or registered trademarks used in this publication are the property of their respective owners.

PTEK Customer Support

Telephone: (408) 448-3342

Fax: (408) 549-9991

E-mail: service@ptekpower.com

Web Site: <http://www.ptekpower.com>

Revision History

Version 1.0.....May 2010

Limited Warranty

PTEK LLC (SELLER) warrants that products are free from defects in material and workmanship and meet the performance specifications stated; however:

- A. SELLER liability under this Warranty is limited to repairing or replacing, at its option, any product delivered not conforming to this Warranty;
- B. This Warranty is limited to a period of three years;
- C. Minor deviations from specifications that do not affect performance are excluded from this Warranty; and
- D. SELLER shall be liable under this Warranty only if:
 - 1. SELLER is promptly notified in writing by the BUYER upon discovery of the failure of any product to conform to this Warranty,
 - 2. The product is returned to the SELLER, with transportation charges prepaid by the BUYER,
 - 3. The Product is received by SELLER not later than ten (10) days after the last day of the two-year period of this Warranty, and
 - 4. SELLER examination of the product discloses the SELLER's reasonable satisfaction that such defects or failures as may exist have not been caused by misuse, neglect, improper installation, repair, alteration, accident, or shipping.

The BUYER will repay freight to and from SELLER on products serviced here under at SELLER's plant; but SELLER may, at its option, elect to perform any repairs here under at the BUYER's place of business.

The foregoing constitutes SELLER's entire Warranty expressed, implied, and/or statutory, except as to title, and state the full extent of SELLER's liability to the BUYER or to any other party for any breach of such Warranty and for damages, whether direct, special, incidental, or consequential; and other than as expressly provided in this document. No Warranties, expressed or implied, including any Warranty or merchant ability or of fitness for a particular purpose, are made. No employee, representative, or agent of SELLER has any authority, expressed or implied, to alter or to supplement the terms of this Warranty.

Warranty Service

The Limited Warranty covers parts and labor to the original purchaser for three years. Damage caused by misuse or shipping is excluded from the Warranty.

PTEK
Customer Service Manager
1723 Little Orchard Street—Unit D
San Jose, CA 95125
(408) 448-3342

Safety Instructions

To maximize user safety and ensure correct device operation, all instructions contained in this section should be read carefully.



Caution: It is important that the user observe all warnings and instructions that are on the device and contained in this manual.

Before Applying Power



Warning: DO NOT OPERATE IN AN EXPLOSIVE ATMOSPHERE

Operation of the Gamma in the presence of flammable gasses or fumes can endanger persons proximate to the site of operation.

Verify that the line voltage is 220VAC.

Ground the Amplifier



Caution: NO NOT REMOVE THE AMPLIFIER COVER

Removal of the exciter cover will invalidate the Gamma Warranty. Component replacement and internal adjustments must be made only by PTEK qualified service personnel.

To minimize shock hazard, the exciter chassis must be connected to an electrical ground, the exciter must be connected to the AC power mains through a three-conductor power cable, with the third wire connected to an electrical ground (safety ground) at the power outlet. Any interruption of the protective (grounding) conductor or disconnection of the protective earth terminal will cause a potential shock hazard that could result in personal injury. If the exciter is to be energized by any other source be certain that the chassis is connected to a separate safety ground.

AC Line Fuses and trips

The Gamma series power amplifiers are provided with an 8 gauge 3 conductor “pig tail” AC Line cord. This should be wired into a breaker box and feed with a 2 pole 35A breaker

Output Connector



Warning: The Flange output connector carries dangerously high RF voltages that present shock and burn hazards. Never operate the Gamma power amp with -out properly terminating the output connector in either an adequately rated load or antenna.

Electrostatic Discharge (ESD)

A sudden discharge of electrostatic electricity can destroy static-sensitive devices or micro-circuitry. Proper packaging and grounding techniques are necessary precautions to prevent damage. Always take industry-standard precautions.

Grounding Methods

Guard against electrostatic damage at workstations by following these steps:

1. Cover workstations with approved anti-static material. Provide a wrist strap connected to a work surface and properly grounded tools and equipment.
2. Use anti-static mats, heel straps, or air ionizers to give added protection.
3. Handle electrostatic-sensitive components, boards, and assemblies by the case or the PCB edge.
4. Avoid contact with pins, leads, or circuitry.
5. Turn off power and input signals before inserting and removing connectors or test equipment.
6. Keep the work area free of non-conductive materials such as ordinary plastic assembly aids and Styrofoam.
7. Use field service tools, such as cutters, screwdrivers, and vacuums that are conductive.

General Safety Rules

- The device must be used in accordance with the instructions for use.
- Electrical installations in the room must correspond to the requirements of respective regulations.
- Take care that there are no cables, particularly mains cables, in areas where persons can trip over them.
- Do not use a mains connection in sockets shared by a number of other power consumers. Do not use an extension cable.
- Only use the mains cable supplied.
- The unit is completely disconnected from the power source only when the power cord is disconnected from the power source. Therefore the power cord and its connectors must always remain easily accessible.
- Do not set up the device in the proximity of heat sources or in a damp location. Make sure the device has adequate ventilation.
- All plugs on the connection cables must be screwed or locked to the chassis housing.
- The device is designed to be used in horizontal position only.
- The device is no longer safe to operate when the device has visible damage or the device no longer functions.
- In case of system malfunction or visible damage to the Transmitter, the device must be shut down and secured against unintentional operation.
- Repairs may only be carried out by a person authorized by PTEK LLC.
- If extensions are made to the Transmitter the legal stipulations and the device specifications must be observed.
- The Transmitter must be switched off and disconnected from all power source before removing any covers.

Table of Contents

Limited Warranty	4
Warranty Service	4
Safety Instructions	5
Preface	12
Website Information	13
Your Comments are Welcome	13
Notes, Cautions, Warnings, and Sidebars	14
1. Overview and Specifications	15
1.1 Overview	15
1.2 Specifications	19
1.2.1 General	19
1.2.2 Electrical	20
1.2.2.1 System Power	20
1.2.3 Environmental	21
1.2.3.1 Noise Level	21
1.3 Packaging and Shipping	22
1.3.1 Rack-Mount Slides	22
2. Installation	24
2.1 Installation Procedures	24
2.2 Mounting in a rack	25
2.3 Installing the Power Supplies	28
2.4 Electrical Connections	29

3. Operation.....	30
3.1 Set Up the System	30
3.2 Power Up the System	31
3.3.4 Final Check	34
3.4 Faults	35
3.4.1 Over Temperature	35
3.4.2 High VSWR	36
3.4.3 Power Supplies	36
3.5 Power Down the System	36
Appendix A. Connector Pinouts.....	37
A.1 Accessory Port	37

List of Figures

Figure 1-1	Gamma Broadcast Transmitter	15
Figure 1-2	Gamma System Block Diagram	16
Figure 1-3	Gamma front Panel	17
Figure 1-4	GammaRear Panel	18
Figure 2-4	Gamma Rack Slides	25
Figure 2-2	Typical Rack Instalation	26
Figure 2-3	Fitting the Gamma into a Rack	27
Figure 2-5	Inserting the power supplies	28
Figure 2-6	Locking the power supplies	28
Figure 2-7	Gamma Rear Panel	29
Figure 3-1	Gamma front Panel	31
Figure 3-2	Gamma front Panel	32
Figure 3-3	Press the Function Key to read Powers	34
Figure 3-4	Press the Function Key to read Voltage and Current	34
Figure 3-5	Over Temperature Indication	35
Figure 3-6	Power Supply LEDs	36
Figure A-1	Accessory Port Pinout	37

List of Tables

Table 1-1	Gamma Series General Specifications	19
Table 1-2	Electrical Specifications	16
Table 1-3	Typical Noise Level of the Gamma Series	21
Table 3-1	Exciter drive powers	18
Table 3-2	Power Readings	25
Table A-1	Accessory Port Pinout Signal Descriptions	38

Preface

This document, entitled *Gamma Operating Manual and User Guide*, provides instructions on how to install, configure, power up, and perform diagnostics on the 7.5 and 10kW Gamma FM Broadcast Transmitter. (see photo below). The information contained within is intended for an experienced system operator with a knowledge of high-performance broadcast transmission systems. The 18RU-high Gamma transmitter is contained in a 19" rack and comprises 3 separate Gamma amplifiers and an exciter.



Gamma FM Broadcast transmitter

Key features of the Gamma FM Broadcast Transmitter include:

- Totally solid-state no-tune construction
- Wide input range from 210 to 264 VAC
- 3-year warranty on all parts and labor
- Remote-control interface
- Optional built-in stereo encoder
- Meets or exceeds all FCC and CCIR standards
- Designed and manufactured in the United States

The Gamma series are FCC-type verified for use on FM stations. Frequency stability for each unit is ensured by using PLL (phase-locked loop) frequency synthesis from a highly stable crystal oscillator. All units incorporate over-temperature protection and VSWR foldback to automatically reduce power output to safe operating levels

Switch-mode power supplies provide consistent performance even when there are frequent power outages and voltage fluctuations that make stressful demands on power dependence. An overview and specifications of the Gamma series Broadcast Transmitters is given in Chapter 1, "Overview and Specifications", of this manual.

Website Information

PTEK corporate and product information may be accessed on the World Wide Web by browsing the website <http://www.ptekpower.com>.

Your Comments are Welcome

We are interested in improving our documentation and welcome your comments and suggestions. You can email your comments to us at docfeedback@ptekpower.com . Please include the document part number in the subject line of your email.

Notes, Cautions, Warnings, and Sidebars

The following icons and formatted text are included in this document for the reasons described:



Note: A note provides additional information concerning the procedure or action being described.



Caution: A caution describes a procedure or action that may result in injury to the operator or equipment. This may involve—but is not restricted to—heavy equipment or sharp objects. To reduce the risk, follow the instructions accompanying this symbol.



Warning: A warning describes a procedure or action that may cause injury to the operator or equipment as a result of hazardous voltages. To reduce the risk of electrical shock and danger, follow the instructions accompanying this symbol.



Sidebar: A “sidebar” adds detail to the section within which it is placed, but is not absolutely vital to the description or procedure of the section.

General Section

Chapter 1

Overview and Specifications

1.1 Overview

The Gamma series are FCC-type verified for use on FM stations. Frequency stability for each unit is ensured by using PLL (phase-locked loop) frequency synthesis from a highly stable crystal oscillator. All units incorporate over-temperature protection and VSWR foldback to automatically reduce power output to safe operating levels

Switch-mode power supplies provide consistent performance even when there are frequent power outages and voltage fluctuations that make stressful demands on power dependence.

The 18RU-high Gamma transmitter is contained in a 19" rack and comprises 3 separate Gamma amplifiers and an exciter.



Figure 1-1. Gamma Broadcast Transmitter




Figure 1-2. Gamma System Block Diagram

The Gamma series is designed within a 18RU-high cabinet 30" deep 21" wide.

Features on the Gamma front panel are shown in Figure 1-3.




Figure 1-3. Gamma Control Panel






Figure 1-4. Gamma Rear Panel

1.2 Specifications

1.2.1 General

Table 1-1 lists general specifications for the 7.5 - 10kW.

Table 1-1. Gamma Series General Specifications

Parameter	Description
Dimensions	<ul style="list-style-type: none"> ⌘ 7.0" (4RU) high ⌘ 19" wide including the front panel ⌘ 24" deep (including the front panel and rear protective flanges; the chassis body itself is 17" deep)
Weight	<p>Total shipping weight is 400 pounds and includes the following:</p> <ul style="list-style-type: none"> ⌘ Chassis 310 pounds ⌘ Packing crate 90 pounds
19" Rack-Mountable with Slide capability	<ul style="list-style-type: none"> ⌘ Left and right rack-mount tabs and handles are attached directly to the chassis. Rack-mount slides are provided
Temperature Operating: Non-Operating:	<ul style="list-style-type: none"> ⌘ 0°C to +30°C ⌘ -40°C to +70°C
Relative Humidity Operating: Non-Operating:	<ul style="list-style-type: none"> ⌘ 8% to 90% non-condensing ⌘ 5% to 95% non-condensing
Maximum Wet Bulb Operating: Non-Operating:	<ul style="list-style-type: none"> ⌘ 27°C, non-condensing ⌘ 35°C, non-condensing
Altitude Operating: Non-Operating	<ul style="list-style-type: none"> ⌘ 0 to 10,000 feet above sea level ⌘ 0 to 40,000 feet above sea level

1.2.2 Electrical

Table 1-2 lists the electrical specifications for the Gamma with FM150ES Exciter.

Table 1-2. Electrical Specifications

Parameter	Description
Frequency Range	⌘ 87.7 MHz to 108 MHz
Audio Input Impedance	⌘ 600 ohms
Audio Input Level (Composite)	⌘ -10 dBm
Audio Input Level R & L Stereo Encoder (<i>optional</i>)	⌘ -10 dBm
Frequency Response (Composite)	⌘ 20 Hz to 15(90) KHz
Pre-Emphasis	⌘ 50 or 75 uS
Harmonic Distortion	⌘ < 0.15% max
Signal-to-Noise Ratio	⌘ > 80 dB rms
RF Output Impedance	⌘ 50 ohms
Output Connector	⌘ 1 5/8 EIA Flange
RF Power Output	⌘ 7600W for 7.5kW ⌘ 10100 for 10kW
Harmonic Attenuation	⌘ < -70 dB
Power Requirements	⌘ 220-264 VAC, 75A (7.5kW) 100A(10kW)

1.2.2.1 System Power

The Gamma series is shipped with 4 (per amplifier dependant on model) “plug in” AC power supplies packed separately to avoid damage. Each AC power supply has a 1500-watt output capacity that auto-ranges single-phase input from a 220 to 264 VAC (47 to 63 Hertz) source. AC is supplied from a rear-mounted power

1.2.3 Environmental

1.2.3.1 Noise Level

Typical noise levels emitted by the Gamma series are outlined in Table 1-3. The chassis is installed with three 4.7" fans mounted side-by-side at the rear of the system. In addition, each AC power supply has its own cooling fan.

Table 1-3. Typical Noise Levels of the Gamma series

Measured at:	1 Meter	2 Meters
Front	81.24 dB	72.57 dB
Rear	86.53 dB	77.93 dB

1.2.3 Packaging and Shipping

The Gamma Series Broadcast Transmitter is packaged in a reusable shipping crate. Approximate weight of an empty crate 90 pounds. The approximate weight of a Gamma series transmitter 310 pounds.

Installation Section

Chapter 2

Installation

2.1 Installation Procedures



Caution: Use industry-standard ESD grounding techniques when handling all components. Wear an antistatic wrist strap and use an ESD-protected mat. Store ESD-sensitive components in antistatic bags before placing them on any surface. Handle all IC cards by the front panel or edges only.

There are no operator serviceable parts inside the Gamma ; therefore, replacement, inspection, or adjustment of internal components within the Gamma requires service by a PTEK technician only. **DO NOT REMOVE THE TOP PROTECTIVE COVER OF THE Gamma CHASSIS** (see following Warning).



Warning: Removal of the top protective cover of the Gamma by anyone other than an authorized PTEK technician will void the product warranty.

2.2 Placement

The transmitter has casters mounted to the bottom of the case to ease movement. Position the transmitter with at least 2 foot clearance from the rear to any wall or obstruction.

2.2 AC Connections

Each power amplifier has a separate AC input. The transmitter is supplied with a 3 X #8 conductor cables. These cables should be connected to an electrical panel with separate 35A breakers.

The exciter and metering each require a 110V AC input and are supplied with separate AC cords with NEMA 5-15P Plug.

2.3 RF Connection

The transmitter has a 1 5/8 EIA Flange output connector. This should be connected to the RF Transmission line customer supplied short bullet required. Example Myat part number 201-010-S

Operation Section

Chapter 3

Operation

This chapter describes:

- How to set up the Gamma system to begin operation
- How to turn the Gamma on and off
- How to monitor and change the operational settings of the Gamma

3.1 Set Up the System

To successfully operate the Gamma Transmitter, it must be connected to a correctly matched antenna, an exciter and a 220V single phase supply.



Warning: PREVENT FIRES!

Ensure each 220V line is connected to a circuit breaker rated at 35A. Use the supplied 8 gauge 3 conductor cable.

Refer to the exciter manual for set up of the exciter. Set the power out put of the exciter to the following power levels dependant on the Gamma model.

Model	Exciter Drive Power
7500	450W
10000	550W

Table 3-1. Exciter drive powers

3.2 Power Up the System

1. Check that the exciter power is as above.
2. Switch the exciter to standby.
3. Operate the breakers to apply 220AC to the Gamma.
4. Check that the stand-by LED on each amplifier is illuminated



Figure 3-1. Gamma Power amplifier

Press the OPERATE key on the control panel of the Gamma. Check that the fans are running on the power amplifiers and that each power amplifier has the indications below:




Figure 3-2. Gamma Front Panel

Switch the exciter to OPERATE

After the start up sequence has completed and the exciter is generating power the Gamma will also produce power.

Typically the power is set at the factory to a mid value i.e. 5000W for the 10000W Gamma. This should now be indicated on the LCD display similar to this:



Figure 3-2. LCD Display Power

Pressing the function button will change the display to read Voltage and Current



Figure 3-3. LCD Display Current & Voltage

Pressing the function key will revert the display to read Forward and Reverse Power. At this point the power can be adjusted to the required output power by operating the raise or lower key as appropriate.

Note all the readings for future reference.

Below is a table of expected power outputs, current and efficiency.

3.3 Power Readings

Power	Gamma 7.5kW		Gamma 10kW	
Output	Current	Efficiency	Current	Efficiency
1000	83	25%	90	23%
1500	102	31%	111	28%
2000	118	35%	128	33%
2500	132	40%	143	36%
3000	144	43%	156	40%
3500	156	47%	169	43%
4000	166	50%	181	46%
4500	177	53%	192	49%
5000	186	56%	202	52%
5500	195	59%	212	54%
6000	204	61%	221	56%
6500	212	64%	230	59%
7000	220	66%	239	61%
7500	228	69%	247	63%
8000			256	65%
8500			263	67%
9000			271	69%
9500			278	71%
10000			286	73%

Table 3-2. power Readings

3.3.4 Final Check

Pressing the FUNCTION key rotates the LCD display through the following screens:



Note: At each screen, pressing the LOWER or RAISE key changes the output power only. PA VOLTS and PA AMPS is another way of indicating the power output, accomplished by multiplying the voltage by the amperage (current), then multiplying the result by the efficiency.

Readings should be recorded weekly to keep track of changes, which may indicate developing problems such as antenna or coax deterioration.

1. After pressing the FUNCTION key on the front of the Gamma, the Forward and Reverse power readings appear on the LCD display (see Figure 3-9).




Figure 3-4. Press the FUNCTION Key to read Powers

2. Pressing the FUNCTION key again will display Voltage and Current on the LCD display (see Figure 3-10).



Figure 3-4. Press the FUNCTION Key to read Voltage and Current

3.4 Faults



Warning: Removal of the top protective cover of the Gamma by anyone other than an authorized PTEK technician will void the product warranty.

3.4.1 Over Temperature

Should the internal temperature exceed 40 degrees Centigrade the power will be reduced to a low value (typically around 300W). At this time the all the controls will be locked out and the stand by LED will flash. After a couple of minuetts the system will retry and power will be reset to the previous value. If the temperature is still in excess of 40 degrees Centigrade then again the power will be reduced as above.




Figure 3-5. Over Temperature Indication

3.4.1 High VSWR

If the load VSWR is high indicated by a high reading on the reverse power meter (greater than 5% of the Forward Power reading). The power will be reduced progressively so as to limit the maximum reverse power. If the Load VSWR improves the power will be increased, ultimately to the previous set value.

3.4.2 Power Supplies

Each power supply has 3 LEDs AC good, DC good and Fault. In the stand-by mode the AC good and Fault will be illuminated. This is a normal condition. In operate mode both the AC good and DC good will be illuminated, the fault LED will be extinguished. Any other combination would indicate a fault with that power supply. Further confirmation of this would be that the other power supply are operating as expected.




Figure 3-6. Power Supply LEDs

3.5 Power Down the System

To power down (turn off) the Gamma, press the STANDBY key, then disconnect the AC power cord from the AC power socket on the rear panel of the chassis.

Appendix A

Connector Pinouts

This appendix provides connector pinouts and signal descriptions for the user I/O connectors that are installed on the Gamma Broadcast Transmitter rear I/O Panel (see Figure 1-4, page 1-3, in Chapter 1, "Overview and Specifications").

A.1 Accessory Port

The Gamma rear I/O Panel provides a 25-pin female DB25 connector as an accessory-port interface. A pinout is provided in Figure A-1; signal descriptions are defined in Table A-1 on page A-2.




Figure A-1. Accessory Port Pinout

Table A-1. Accessory Port Pinout Signal Descriptions

Pin	Signal Function
1	Forward power DC indication; 2.4V = 3000W
2	Final voltage DC indication; V = V/10
3	<i>Not used</i>
4	<i>Not used</i>
5, 6, 18, 19	<i>Not used</i>
7	<i>Not used</i>
8	Raise; ground to raise the output power
9	<i>Not used</i>
10	<i>Not used</i>
11, 12, 23, 24	Ground
13	Remote on (ground to turn the unit on momentarily only)
14	Reverse power DC indication; 2.4V = 3000W
15	<i>Not used</i>
16	<i>Not used</i>
17	<i>Not used</i>
20	Lower; ground to lower the output power
21	Final current DC indication; Full scale = 2.5V
22	<i>Not used</i>
25	Remote off (ground to turn the unit off momentarily only)