

## Accessory Connector

---

Pin Number(s)	Accessory Function
1	Forward Power DC Indication $2.4V=600W$
2	Final Voltage DC Indication $V=V/10$
3	Output Power out of range Hi (10V)
8	Raise; Ground to raise the output power
10	Serial; Used when 2 or more amplifiers are combined
13	Remote On, Ground to turn the unit on (momentary)
14	Reverse Power DC Indication $2.4V=600W$
5,18,6,19	48V Output (Fan supply for combiners)
15	Output Power out of range Lo (10V)
20	Lower; Ground to lower the output power
21	Final Current DC Indication Full scale = 2.5V
22	Talk; Used when 2 or more amplifiers are combined
25	Remote off, Ground to turn the unit off (momentary)
11,12,23,24	Ground